Assignment 1: A Simple Data Link Layer Protocol

Use the RS232 (or Wi-Fi, or Socket) to setup a simple link layer protocol between two computers. The protocol fulfills the following tasks:

- 1. Read the small jpeg file umdlogo.jpeg or other files in a binary format using the transmitter computer.
- 2. Pack the bit stream of the file into many I-frames with sizes of 1024bit (or in other sizes) payload.
- 3. Each frame contains a header of 011111110.
- 4. Each frame has a frame counter (1Byte).
- 5. Each frame attach with a CRC check by using a divisor 110101.
- 6. At the receiver computer, realize frame synchronization (find the header) and CRC check.
- 7. Use stop and wait automatic repeat request (ARQ) for error control.
- 8. Use the timer to control the ARQ.
- 9. The ACK is without CRC and instead use a simple repeat diversity by extending to 1 Byte.
- 10. Write the receiver bit stream to a file in binary format and show it.
- 11. Generate random errors during the propagation and use it to validate the CRC functionality.
- 12. Demonstrate your project in lecture.

Other suggestions

- 1. Use the data rate greater than 19.2Kbps to save the transmission time.
- 2. Use a build-in test frame to realize the function before actually transfer the jpeg file.
- 3. Be sure to use a *null modem cable* to connect two computers
- 4. Working in groups or individually is both accepted. However, no more than two students are within one group.